

2

## Instructions

Tie pulleys supplied to ridge knuckles with the long ropes put through each pulley to hang down each side 1. Repeat this on every bay. 3

Clamp the lifting poles together using the shackles supplied 2. Tie one end of the rope to the lifting pole 3. The other end must be fed behind the eave rail 4.

To fit wires: wrap a webbing **5** strop attached with a shackle around each corner leg at lining wall height and attach small pulleys to opposite corners of the tent **6**. Feed a wire through the pulleys with a bottlescrew and 2 clamps on each end **7**.

Make sure bottlescrew is fully opened and hook on to the shackle at opposite corners. Pull wire tight through bottlescrew then tighten clamps (8). Close bottlescrew as tight as possible to tension the wire.

Please turn over...



1

## Linings fitting instructions



To stop the wire from pulling out or bowing when you attach the roof lining, attach a shackle 9 or lining clamp in the keder track **10** to every leg and secure the wire.

Pull up the lifting poles to shoulder height, then attach the roof **11** extensions by tieing the webbing straps in a bow like a shoelace.

Lift poles to above eave height, **12** then hook the linings up on the wire all the way round **13**. Tie the corners of each lining roof with the webbing straps supplied, then fasten all the velcros together. Pull the poles up as high as you can to tension the roof 14

To hang the walls, hook on to the main wire **15**. Window drapes attach to the velcro sewn on the edge of the roof linings. Swagged or pleated pelmets velcro on to the roof linings also **16**. On the walls there is a pocket at the bottom for the wall weight to slide in to weigh down the walls (17).

Industrial Fabrics

**INNOVATIVE DESIGN** custom made with customers in mind







Custom Covers (1984) Ltd Quayside Road, Bitterne Manor Southampton SO18 1AD

Tel: +44 (0)23 8033 5744 Fax: +44 (0)23 8022 5581 sales@customcovers.co.uk www.customcovers.co.uk